

Product Name :
Electric Stirrer and Mixer, 1200 W, with Whisk

Product Code :
LIM-CAT-L0022-00002



Description :

Electric Stirrer and Mixer, 1200 W, with Whisk

Technical Specification :

Electric stirrer / mixer, 1200 W, with whisk

Adjustable 6 Speed High and low gears features 6 speeds with self-locking switch for tackling wide variety of materials. With a screw shaped dual-paddle, the machine mixes effectively and thoroughly, which greatly saves your time and prevent the mortar from splashing everywhere.

Overheating protection Enlarge the air outlet and adopt a porous heat dissipation design ,which can spread heat faster, work longer and last longer, The cement mixer will automatically power off when the machine is overheated.

Easy Operation Dual ergonomic handle on both sides covered with specially shaped material, and with Operation Locking Switch, you don't need to hold down the trigger while mixing, which help to reduce the working strength and fatigue of fingers.

External carbon brush holder design The all-copper carbon brush holder is externally designed, which can easily and quickly replace the carbon brushes and make maintenance easier.

Electric Paddle Mixer Cement Plaster Paint

Stirrer Whisk

Power supply 220V/1ph/50hz

Double handle for operation easier.

Triple reduction gears to lower speed and higher torque.

Tow mechanism speeds allows the user to set the mixing speed to match different applications.

All metal gear housing for high strength and lifetime

2 speed gearbox 460/750 rpm
Supplied with 2 whisks
Dimension 31 x 32 x 20.2 cm;
Weight 3.48 Kg.

Electric Stirrer and Mixer, 1200 W, with Whisk, Electric Stirrer and Mixer, 1200 W, with Whisk Bulk Suppliers, Electric Stirrer and Mixer, 1200 W, with Whisk Tools, Electric Stirrer and Mixer, 1200 W, with Whisk Electric Stirrer and Mixer, 1200 W, with Whisks, Electric Stirrer and Mixer, 1200 W, with Whisk Manufacturers, Electric Stirrer and Mixer, 1200 W, with Whisk Suppliers from India, China, Kenya.



Laboratory instruments manufacturers India