

**Product Name :**  
Welding simulator Trainer for MIGMAG TIG Arc Welding

**Product Code :**  
LIM-CAT-L0043-00018



**Description :**

Welding simulator Trainer for MIGMAG TIG Arc Welding

**Technical Specification :**

Welding simulator Trainer - for MIGMAG TIG Arc Welding

The simulator is composed of the following: - (ENG) AR Welding Trainer welding torches for GMAW/FCAW, SMAW and GTAW and standard accessories.

Software for GMAW, SMAW, FCAW-G, FCAW-S for standard coupons in carbon steel, stainless steel and aluminium, and E-Learning (LMS).

Workstation for positioning the welding coupons in different positions.

Developed based on the most frequent parts of the shipbuilding industry.

Part for GMAW welding in carbon steel. Butt and horizontal welding with splice and obstacle. Corner weld with continuity in PB position, PB-PD corner weld with appendages and splices. J" and "V" shaped return weld.

Part for GMAW welding in carbon steel. It has internal welds in different angles and different positions in the same trajectory (horizontal, vertical, 6G, under the ceiling).

Developed based on the most frequent parts of the shipbuilding industry, includes 14 passes, with 3/32" open root and 1/8" root face. Open root with v- groove+.

Welding simulator Trainer for MIGMAG TIG Arc Welding, Welding simulator Trainer for MIGMAG TIG Arc Welding Bulk Suppliers, Welding simulator Trainer for MIGMAG TIG Arc Welding Tools, Welding simulator Trainer for MIGMAG TIG Arc Welding Welding simulator Trainer for MIGMAG TIG Arc Weldings, Welding simulator Trainer for MIGMAG TIG Arc Welding Manufacturers, Welding simulator Trainer for MIGMAG TIG Arc Welding Suppliers from India, China, Kenya.



## Laboratory instruments manufacturers India