

Product Name :
Hydraulic Sample Extruder Hand Operated

Product Code :
LIM-CAT-L0044-00009



Description :

Hydraulic Sample Extruder Hand Operated

Technical Specification :

Hydraulic Sample Extruder - Hand Operated

This extractor frame is used for taking out soil samples compacted or undisturbed, from 100 mm dia and 150 mm dia cylinders such as Core Cutters, Proctor moulds, c. B. R. Moulds etc.

60 cm piston stroke.

50kN Pushing force.

Adapter rings and ejector discs for 38, 50, 75, 100 & 150 mm dia sampling tubes or moulds, included.

Built-in safety valve to prevent loading beyond 50kN