

**Product Name :**  
Aggregate Impact Tester

**Product Code :**  
LIM-CAT-L0044-00032



**Description :**

Aggregate Impact Tester

**Technical Specification :**

Aggregate Impact Tester

The aggregate impact value of coarse aggregate provides a relative measure of the resistance of an aggregate to sudden shock or impact. The oven dried and accurately weighed aggregates are subjected to a total of 15 blows of specified weight and fall and percentage of fines formed in terms of the total weight of the sample is expressed as the aggregate impact value.

Product Type : Aggregate Impact Testing Machine

Internal diameter: 102mm

Depth: 50mm

Thickness 6.3mm