

**Product Name :**  
Workstation with 4 Independent Power Supplies

**Product Code :**  
LIM-CAT-L0002-0001



**Description :**

Workstation with 4 Independent Power Supplies

**Technical Specification :**

Workstation with 4 independent power supplies

Work bench with high flexibility and autonomy.

It is designed to allow the performance of wiring experiments in the area of civil and industrial installations and must offer the maximum work versatility in the laboratory. It is possible to store all the works that have not been completed in a single lesson and leave the frame free for other students.

The power supplies is provided by means of a vertical module placed by the side of the work panels and all the supplies shall be protected according to current regulations.

For each side the following power supplies are provided:

2 three-phase + N + PE, 16A outputs on 36A safety terminals according to IEC 61010-1; protection through differential, magneto-thermal, 4-pole, 16A automatic switch, pilot lamp and key switch for teacher control.

4 outputs on 10/16 A single-phase mains sockets, protection through differential, magneto-thermal, 16A automatic switch and pilot lamp.

2 outputs isolated from the mains, 0 ÷ 12 ÷ 24Vac, 4A on isolated terminals, protection through magneto-thermal, automatic switch.

2 optical and acoustic circuit testers on isolated terminals, protection through fuses.

Workstation with 4 Independent Power, Workstation with 4 Independent Power Bulk Suppliers, Workstation with 4 Independent Power Tools, Workstation with 4 Independent Power Tool Kits, Workstation with 4 Independent Power Manufacturers, Workstation with 4 Independent Power Suppliers from India, China, Kenya.



## Laboratory instruments manufacturers India