

Product Name :
Standard API Fluid Loss Press

Product Code :
LIM-CAT-L0047-00004



Description :

Standard API Fluid Loss Press

Technical Specification :

The Filter Press API is a low pressure, low temperature (LPLT) filter press that provides an easy, effective way to evaluate the filtration properties of a drilling fluid. The Filter Press API consists of a pressure cell, frame, pressure source, filter medium, and a graduated cylinder. It conforms to API specifications, and is suitable for both field and lab use.

Features:

- Threaded cell and set screw cell available.
- Single and double opening cells available.
- Pressurization method includes CO2 Cartridges, bottled Nitrogen, or an in-house (user provided) source.
- Easy and safe to operate.
- Filter media includes the API standard Filter Paper, Ceramic Discs of several calculated porosities, and various mesh-sized screens.

