

**Product Name :**  
Sand Content Analyser

**Product Code :**  
LIM-CAT-L0048-00011



**Description :**

Sand Content Analyser

**Technical Specification :**

One of the primary functions of a drilling fluid is to carry drilled solids from the well bore. These solids are a contaminant, and if left in the system, can lead to numerous problems. The ofite sand content kit determines the volume percent of sand-sized particles in the drilling fluid. Sand-sized particles as any material larger than 74  $\mu\text{m}$  (200-mesh) in size. The test can be performed on low solids fluids as well as on weighted fluids. The kit consists of a glass tube graduated to read percent (%) by volume, a funnel, and a 200-mesh sieve contained in a cylindrical shaped holder. Consists of sand content kit, complete, with sieve, funnel, graduated tube, wash bottle & carrying case.