

Product Name :
Marshall Extruder Hydraulic

Product Code :
LIM-CAT-L0049-00017



Description :

Marshall Extruder Hydraulic

Technical Specification :

The extractor frame is used for taking out soil samples compacted or undisturbed, from 100mm dia and 150mm dia cylinders such as Core Cutters, Proctor moulds, C.B.R. moulds etc.

Specification:

It consists of a 50Kn capacity hand operated, hydraulic jack mounted on a suitable frame.

Two plungers, one for 4"/100mm dia and the other of 6"/150mm dia moulds are supplied Height of thrust plate is adjustable.