

**Product Name :**  
Surface Gauge

**Product Code :**  
LIM-CAT-L0051-00048



**Description :**

Surface Gauge

**Technical Specification :**

The Universal Surface Gauge is used for accurately scribing lines, transferring measurements or probing surfaces in inspection work.

Adjustable beam, scribe, column c.200 mm.

A fully hardened and ground base which serves as an accurate reference surface

A machined Vee groove in the base allows the gauge to be used conveniently on curved surfaces

A Vee groove at the front end allows the spindle to adjust to any angle above or below the base allowing it to be used as a height gauge and also as a depth gauge.

Two retractable pins allow the gauge to be located against the edge of a surface plate or T-slot for linear work