

**Product Name :**  
HSS- Plain Milling Straight-Tooth Cutter

**Product Code :**  
LIM-CAT-L0065-00002



**Description :**

HSS- Plain Milling Straight-Tooth Cutter

**Technical Specification :**

Plain Milling Cutter, also called Surface Milling or Slab Milling, is milling flat surfaces with the milling cutter axis parallel to the surface being milled.  
Generally, plain milling is done with the workpiece surface mounted parallel to the surface of the milling machine table and the milling cutter mounted on a standard milling machine arbor.  
The arbor is well supported in a horizontal plane between the milling machine spindle and one arbor supports.  
Arbour Diameter ? 22, 27, 40mm.