

**Product Name :**  
Fruit Washer With Grinder

**Product Code :**  
LIM-CAT-L0068-00004



**Description :**

Fruit Washer With Grinder

**Technical Specification :**

Fruit Washer With Grinder

Performance: 1000-2000 kg/h

Electricity demand: 3 kW, 400 V, 16 A, three-phase

Material: WNr. 1.4301, AISI 304 stainless steel

Dimensions: 710x3200x2120mm

Outlet height: 1280 mm

Weight: 200 kg

Tub capacity: 120 L/team

Wash water supply: (20-100L/h depending on setting)

Water connection: 3/4 quick coupling

IP65 certified electronics

Massive crushing hammer mill (available for beets and quinces)

Noise emissions: 60-70 dB

The fruits go to the inlet hopper, after quenching the elevator to the fruits under the secondary sprays of clear water

Easy to clean, with a modular solid polypropylene/acetal lift, infinitely variable speed in both directions, with 2pcs rotating, 2pcs fixed wheels or vibration-free feet.

It requires only minimal maintenance.

Options available:

---

Variable diameter sieve: to modify the texture of the wort.

Stop 'n' Go system: membrane sensor, which allows the fruit washer/grinder and the belt press to work together

Dosing module: sliding door with limit switch, which allows dosing from the crusher to the baler in complete safety.



## Laboratory instruments manufacturers India