

Product Name :
Stone Fruit Sieve

Product Code :
LIM-CAT-L0068-00005



Description :

Stone Fruit Sieve

Technical Specification :

Stone Fruit Sieve

The machine is suitable for pitting stone fruits. Chopped fruit can be delivered in a container, a pasteurizer, a jam extractor, suitable for use with a pump screw or hand-powered collector handle

Quick change of the sieve

Low maintenance

Perfect for extracting seeds from mash

Specifications:

Performance: 500-1000 kg/h

Electricity demand: 2.2 kW, 400 V, 6 A, three-phase

Material: AISI 304 stainless steel

Dimensions: 650x1100x1140mm

Weight: 100 kg

IP65 certified electronics

Entrance height: 1050 mm

Output height: 380 mm

Rotor rubbers for the food industry

Adjustable distance between sieve and rotors

With feed screw in the inlet hopper. With 2 pcs rotating, 2 pcs with fixed wheels, or 4 pcs with vibration-free feet.

It requires only minimal maintenance.

The sieves can be replaced easily and quickly.
A sieve of chosen diameter is included in the price
DN 65 connection for the outlet
Inverter: rotor speed control
Sieves:
0.8 mm diameter sieve: berries, pulp
1.5 mm diameter sieve: berries, pulp
3 mm diameter sieve: apple, pear
5 mm diameter sieve: cherry
8 mm diameter sieve: plum, apricots
10 mm diameter sieve: peach, mango
Custom diameter sieve



Laboratory instruments manufacturers India