

Product Name :
Brake Test Stand

Product Code :
LIM-CAT-L0072-00021



Description :

Brake Test Stand

Technical Specification :

Brake Test Stand

Roller brake tester for cars and vans

Robust galvanvanized construction

The Roller Brake Tester for cars and vans has a robust galvanvanized construction. It has the modern strain gauges and meets the current requirements of the brake testing guidelines. The rollers are plastic coated.

Digital display cabinet display: Two 4-digit 7-segment displays for measured values in daN, 4-digit 7-segment display for the difference in %, self-diagnostic function to ensure correct readings.

Features: ASA live stream interface, Speed sensor, DMS-measurment technology, 4 wheel drive (Except vehicles with lock), Self calibration

Technical Data:

Wheel load 3 tons, Motor power min. 2 x 3 kW, Power supply 400 V, Test speed 5 km/h, Measuring range 0 - 6 kN, Track width 800 - 2200 mm, Roller diameter 200 mm, Roller length 700 mm, Friction coefficient 0,8

Including Roll Cover

Laboratory instruments manufacturers India

