

Product Name :
Engine Pressure Loss Tester

Product Code :
LIM-CAT-L0072-00044



Description :

Engine Pressure Loss Tester

Technical Specification :

Engine Pressure Loss Tester
For diagnosis of compression pressure loss
Suitable for analysis of intake and exhaust valves, piston rings or cylinder liner, cylinder head or head gasket
Universally applicable
Integrated pressure reducer
Necessary working pressure: 1,0 bar
For use on engines at operating temperature
In sturdy plastic case
Analysis Results:
Exhaust valves leaking:air noise in exhaust tract, manifold or cylinder head on exhaust side.
Intake valves leaking:air noise in intake tract, on cylinder head on intake side.
Piston rings, pistons, cylinder bore defective:Air noise at crankcase ventilation or at oil dipstick.
Cylinder head gasket defective:air noise in neighboring cylinder, spark plug bore.
Cylinder head gasket defective or crack in cylinder head:air noise or bubbling in cooling system or expansion tank.

Laboratory instruments manufacturers India

