

**Product Name :**  
Engine Pressure Loss Tester

**Product Code :**  
LIM-CAT-L0072-00044



**Description :**

Engine Pressure Loss Tester

**Technical Specification :**

Engine Pressure Loss Tester  
For diagnosis of compression pressure loss  
Suitable for analysis of intake and exhaust valves, piston rings or cylinder liner, cylinder head or head gasket  
Universally applicable  
Integrated pressure reducer  
Necessary working pressure: 1,0 bar  
For use on engines at operating temperature  
In sturdy plastic case  
Analysis Results:  
Exhaust valves leaking:air noise in exhaust tract, manifold or cylinder head on exhaust side.  
Intake valves leaking:air noise in intake tract, on cylinder head on intake side.  
Piston rings, pistons, cylinder bore defective:Air noise at crankcase ventilation or at oil dipstick.  
Cylinder head gasket defective:air noise in neighboring cylinder, spark plug bore.  
Cylinder head gasket defective or crack in cylinder head:air noise or bubbling in cooling system or expansion tank.

---

# Laboratory instruments manufacturers India

