

Product Name :
Antifreeze Tester

Product Code :
LIM-CAT-L0072-00049



Description :

Antifreeze Tester

Technical Specification :

Antifreeze tester

Works With Your Engine Hot Or Cold: Disc-type tester is accurate at all temperatures; Tests your coolant's freezing point and helps guard against coolant overprotection

Easy To Read: Count the number of floating disks in the coolant tester and compare it to the chart on the body of the tester, which shows coolant freezing temperature in both Celsius and Fahrenheit; Five floating discs means ideal protection

Prevents Overprotection: Includes a special 6th disc which shows overprotection and a loss of coolant efficiency due to a bad water-coolant mix; Our antifreeze and coolant tester has you covered

Simple And Powerful: Features a clear body that makes it easy to check your coolant for impurities, such as rust; All-in-one coolant tester kit features a simple yet powerful design

Works On Any Vehicle: Test diesel antifreeze, RV antifreeze, camper antifreeze, marine antifreeze, just about any vehicle's antifreeze coolant with ease with our coolant tester

Robust and unbreakable plastic design

For checking the radiator antifreeze

Tests ethylene glycol (ethanediol)-based antifreeze-water mixtures

Display accuracy: 0.5°C

Elastomeric priming ball remains elastic and fully functional at all temperatures

Hydrostatic lock prevents automatic air leakage and air trapping.



Laboratory instruments manufacturers India