

**Product Name :**  
Caliper Drum Brake

**Product Code :**  
LIM-CAT-L0072-00055



**Description :**

Caliper Drum Brake

**Technical Specification :**

Caliper drum brake

Digital drum brake caliper measuring range digital calipers for measuring brake drum wear, The caliper jaws - have two pegs that act as depth stops and also ensure the measurements are taken parallel.

There are two sets of pegs a higher and lower set that allow measurement to be accurately taken at two heights.

High Quality Caliper - The jaws and slide beam are made from hardened stainless steel.

Stainless, hardened Design

Reading parts matt chrome plated

With locking screw

Reading 0.05 mm

Measuring range inside: 40 - 300 mm

Beak length: 90 mm

