

Product Name :
Pneumatic Glove Tester

Product Code :
LIM-CAT-L0072-00074



Description :

Pneumatic Glove Tester

Technical Specification :

Pneumatic Glove Tester

For regulatory control of gloves before use.

Practical and portable manual pneumatic system.

Enables verification by inflation and immersion in water.

Before each use, the electrically insulating gloves always checked and a repeat test is carried out every 6 months. The pneumatic glove tester is suitable for class 00 (500 V) and 0 (1000V) during the repeat test.

The glove is filled with air and immersed in water by pressing the pushbutton of the tester. This process allows

the detection of the smallest defects of a glove by visual inspection.

Dimensions: \varnothing 130 x 160 mm.