

Product Name :
Tube Cutters

Product Code :
LIM-CAT-L0007-00011



Description :

Tube Cutters

Technical Specification :

Made of high quality metal, extremely sharp. The body of the tubing cutter is made of lightweight, durable aluminum alloy casting.
Adjustable knurled knob provide stronger grip when use, grooved guide rollers ensure square cuts more easy and labor saving, even if close to flared pipe end.
Use the portable tubing cutter to quickly and precisely cut pipe tubes by rotate the pipe when compressing.
Fold-away slide lock reamer deburring blade to clean any burrs left after cutting, also ensures a better connection.
Cuts copper, brass and aluminum tubing
Capacity 3 to 28 mm
Metal alloy die cast body
Steel rollers with flare cut off groove

