

Product Name :
Locking Piercing Plier

Product Code :
LIM-CAT-L0007-00037



Description :

Locking Piercing Plier

Technical Specification :

Fast refrigerant recovery with pliers that clamp on and pierce tube. Simple to use and light weight. Adjust pliers to proper size, align tip to center of tube, clamp down and pierce with quick action. These pliers work on copper tubing sizes ranging from 1/4 to 7/8 inch OD. Piercing tip is self-sharpening but also easily replaceable. Tube expander kit 10-42mm in carry box.